

## CABINET BOX

1. To make the Main Cabinet. Glue the Back to the back edge of the Hinged Base.
2. Glue one of the Sides to the Back and Hinged Base pieces.
3. Glue the large Shelf pieces into cabinet by slotting the notches into the grooves on the Back and Side pieces.
4. Glue the other Side piece to the Back and Hinged Base pieces making sure to slot the notches from the Shelves into the grooves as you do. Leave the Hinged Top off for now.
5. To make the Front Cabinets. The Base and Top pieces have a quarter circle cut out in the corners. For the left hand cabinet this cut needs to be in the top right hand corner. For the right hand cabinet, this cut needs to be in the top left hand corner. Build your cabinets keeping your base pieces in this orientation.
6. For the left hand cabinet, glue the Back piece to the back edge of the Base piece. Glue the Side piece to the Base piece on the opposite side to the corner cut out.
7. Glue the Cabinet Shelves into the left hand cabinet by slotting the notches into the grooves on the Back and Side pieces.
8. Glue the Hinged Side piece to the Back and Base pieces making sure to slot the notches from the Shelves into the grooves as you do.
9. Glue the Top piece to Base and Side pieces making sure the cut out corner matches up with the one on the Base piece. Glue the Shelf front pieces to the cabinet gluing them to the front edge of the shelves and the edges of both Side pieces.
10. Repeat steps 6-9 for the right hand cabinet.
11. Slot the front cabinets into the hinges on either side of the main unit by slotting the pegs into the holes in the main unit.



- Glue the Hinged Top to main cabinet Sides and Back pieces locking the front cabinets in place.
12. Glue the main cabinet onto the large Base piece so it sits along the back edge and the hinge semi circles line up with semi circles notches on the Base piece. Glue the large Top piece onto the main cabinet, again lining up the semi circle notches.
  13. All the drawers can be made in the same way, no matter the size. Glue the Back piece to the back edge of the Base piece. Glue the Side pieces to the Base and Back pieces. Glue the Front onto the Back and Side pieces.
  14. Slot all drawers into the main cabinet.