



Santa Sack Instructions

Top Edge

1. Taking the Santa Sack fabric, with the red band towards the top. Turn the white strip over towards the back so that the red band is now the top of the fold.
2. Sew from edge to edge 5cm down from the folded edge so that you create a channel for the drawstring

Side Seam

3. Fold in half (right side facing) so writing is on the inside and keep drawstring channel.
4. Stitch from top to bottom on the side seam approx. 2cm in from selvedge edge but stopping at the top drawstring channel, reinforcing the seam as this is the sack opening.

Bottom

5. Stitch approximately 2cm from bottom edge, reinforcing the start and end.
6. Cut any excess fabric off, then turn right side round
7. Thread ribbon, etc through the top channel, use a safety pin or similar to push the ribbon through the channel for the drawstring.